

# 650



## CARE INSTRUCTION

- Dipped PVC glove with a seamless cotton support.
- The nominal size is for a glove that has been stretched to fit on the hand.
- Do not use with chemical substances, other than those tested, without carrying out a test first.
- Ideal for handling work when oils, chemical substances or hydrocarbons are present (specially treated).
- Permeation performance level (EN374-3) information does not reflect actual duration protection in the workplace due to other factors influencing performance.
- Recommended for use by those allergic to natural latex.
- Store in a dry place, away from the light.
- Decontaminate/cleanse with running water, while on hands, using a neutral detergents if required.

## MATERIAL

**Liner:**  
Cotton, Rubber Urethane

**Coating:**  
PVC

## COUNTRY OF ORIGIN

Malaysia

## PACKAGING

1 pair in a bag  
120 pairs in a carton

## SIZE

8/M 9/L 10/XL 11/XXL

## STANDARDS

89/686/EEC **CE0120**  
CAT.III

EC Type Examination Certificate  
From SGS United Kingdom Ltd.,  
202B Worle Parkway,  
Weston-super-Mare, BS22 6WA, UK  
Notified Body No.0120

### EN 420:2003

Dexterity  
Level 5  
(Min.1 - Max.5)

### EN 388:2003



4 1 2 1

### Mechanical risks

Abrasion (Min.0 - Max.4) .....	4
Cut (Min.0 - Max.5) .....	1
Tear (Min.0 - Max.4) .....	2
Puncture (Min.0 - Max.4) .....	1

### EN 374-2:2003



### Penetration

Level2 Inspection level G1 AQL: <1.5  
(Min.1 - Max.3)

### EN 374-3:2003



J K L

### Permeation

J: Level3 n-Heptane - CAS No.142-82-5  
K: Level6 Sodium hydroxide 40% - CAS No.1310-73-2  
L: Level3 Sulphuric acid 96% - CAS No.7664-93-9  
(Min.0 - Max.6)

